



Product information

S902





Thin client and CPU holder, printer board.

Thin client holder (21870) with tension strap for mini PCs for attachment to the metal console on the table. Can be attached on the left or right side by the user. Made of folded sheet steel, powder-coated. The mini PC is secured with a tension strap.

Height-adjustable CPU holder (21872) with tension strap for storing the CPU under the tabletop. Construction consisting of a vertical rectangular tube with mounting profile and an inserted inner profile with welded base plate. Base with 4 rubber pads to prevent slipping. Powder-coated steel parts. Height adjustment is via a knurled screw on the outer profile. The CPU is secured with a tension strap. The holder is attached to the metal console with screws. It can be attached to the left or right of the table and can face either inwards or outwards.

Printer board (21873) for storing a printer underneath the tabletop. Construction consisting of 2 arms made of folded sheet steel onto which the shelf is screwed. Steel parts powder-coated. The arms are attached to the table crossbar with screws. The printer board can be attached to the left or right side of the table.

CPU holder with tension strap (24291) for storing the CPU underneath the tabletop. Construction made of bent steel wire. Steel parts powder-coated. The CPU is secured with a tension strap. The mount is attached to the metal bracket—or, on S902 Base models, to the tabletop—using screws. It can be mounted on the left or right side of the table, facing inward.

					
S902		21870	24291	21872	21873
	Type	Thin client holder	CPU holder	Height-adjustable CPU holder	Printer board
	for Type S902...	Pro, ProRail	Base, Pro, ProRail, Flex	Pro, ProRail	Pro, ProRail
	w×h×d cm	17×11×4	13×23×49	6×28×48	45×58×24