



Material Notes

Cleaning and maintaining laminated surfaces, such as chipboard panels (LIGNOpal), CPL, LIGNOdur, phenolic (HPL) boards, MDF, or chip-plywood boards.

General information: Laminated furniture surfaces do not require intensive cleaning since the non-porous surface ensures simple maintenance. Clean off minor soiling with a moderately damp cloth or sponge and remove more stubborn dirt with a little water and a gentle cleaning agent or suds. Quickly remove all excess water with a cloth or sponge. Then wipe wooden edges with dry rags.

Do not use any aggressive and/or abrasive cleaning materials. These can damage the surface.

Only use **cleaning cloths, rags, or natural or synthetic sponges for cleaning.** Do not use any synthetic cleaning pads, microfiber cloths, or steel wool.

Adhering limescale deposits/stains can be eliminated with a warm 10% vinegar or citric acid solution. Then wipe over again with clean, warm water.

If possible, remove any **marks** made by ballpoint pens, felt pens, marker pens, etc. before they dry in.