




http://links.vs-service.com/downloads/70-266_V02_DEEN_Desksensor.pdf

Montageanleitung

Desksensor

Bestimmung: Der vorliegende Sensor ist ausschließlich für die Nutzung in geschlossenen Räumen konzipiert. Für nicht bestimmungsgemäße Nutzung wird keine Haftung übernommen.

Allgemeiner Hinweis: Lesen Sie diese Anleitung und vor allem die Sicherheitshinweise vor Benutzung der Produkte genau durch und beachten Sie diese. Bewahren Sie die Anleitung zum späteren Nachlesen sorgfältig auf und geben Sie diese an andere Benutzer weiter.

Allgemeiner Sicherheitshinweis: In dieser Anleitung verwenden wir folgende Symbole und Hinweise:



Wichtig! Bei diesem Symbol handelt es sich um einen wichtigen Montagehinweis.



Achtung! Bei diesem Symbol handelt es sich um einen sehr wichtigen Hinweis.

Im Internet: Sie finden diese Anleitung im Internet (siehe Kopfleiste).

Lieferumfang: Das Produkt wird fertig montiert ausgeliefert.

Betrieb: Beachten Sie die Hinweise auf den folgenden Seiten.

Fehlersuche und Service: Bei eventuell auftretenden Fehlern wenden Sie sich bitte an den VS-Kundendienst: kundenservice@vs-moebel.de

Assembly instruction

Desksensor

Intended use: The current sensor is intended exclusively for use in closed premises. No liability will be assumed for any use other than that intended.

General comments: Read these Instructions and, in particular, the safety instructions carefully before using the products and adhere to these. Keep these Instructions in a safe place for future consultation and communicate them to other users.

General note on safety:

The following symbols and notes are used in these Instructions:



Important!
This symbol indicates an important assembly note.



Caution! This symbol indicates a very important note.

On the Web: You can find these instructions on the Internet (see header).

Scope of delivery: The product is supplied fully assembled.

Use: Please take account of the notes on the following pages.

Troubleshooting and service: If any faults occur, please contact the VS Customer Service: kundenservice@vs-moebel.de

Weitergabe und Entsorgung: Achten Sie darauf, bei einer Weitergabe des Produkts auch diese Anleitung mit zu übergeben. Für eine umweltfreundliche Entsorgung informieren Sie sich bitte bei Ihrer zuständigen Kommune. Die gekennzeichneten E-Komponenten dürfen nicht über den Hausmüll entsorgt werden. Sie müssen von dem Möbel getrennt werden, bevor das Möbel der Entsorgung zugeführt wird. Die Entsorgung erfolgt an zugelassenen Sammel- und Rücknahmestellen.



Transfer and disposal: Please note that if the product is transferred to a new owner then it must be accompanied by these Instructions. Please contact your responsible local authority department regarding environmentally friendly disposal. The indicated electric and electronic components must not be disposed of with the ordinary waste. They must be removed from the furniture unit before sent for disposal. It must be disposed of at authorized collection and return points.




1.

Montage Assembly

1.1

Stecken Sie den Desksensor (1) in den T-Splitter (2). Befestigen Sie anschließend T-Splitter und eingesteckten Sensor mit zwei Schrauben (3) an der Tischplatte (die Position ist vorgekört).

Wichtig! Der Desksensor ist so montiert, dass er ohne Werkzeug nicht oder nur erschwert herausgezogen werden kann.



Ziehen Sie dann das Handschalterkabel (4) aus der Mastersäule und verbinden Sie es mit dem T-Splitter. Stecken Sie anschließend das RJ45 Kabel (5) in die Handschalterbuchse und verbinden Sie auch dieses mit dem T-Splitter.

Insert the desk sensor (1) in the T-splitter (2). Then fasten the T-splitter and inserted sensor to the desk top using two screws (3) (the position is prepunched).

Important! The desk sensor is mounted in such a way that, without tools, it cannot be pulled out or can only be pulled out with difficulty.

Then pull the cable for the handswitch (4) from the master column and connect it to the T-splitter. Then insert the RJ45 cable (5) into the handswitch jack and connect this to the T-splitter as well.

